



INDUSTRIAL PANEL COMPUTERS

(Models AC220, AC240, AC250, and AC270)

(Manual Part Number MAN-UTPPC-001)

WARNING!

Programmable control devices such as the Industrial Panel Computers must not be used as stand-alone protection in any application. Unless proper safeguards are used, unwanted start-ups could result in equipment damage or personal injury. The operator must be made aware of this hazard and appropriate precautions must be taken.

In addition, consideration must be given to the use of an emergency stop function that is independent of the programmable controller.

The diagrams and examples in this user manual are included for illustrative purposes only. The manufacturer cannot assume responsibility or liability for actual use based on the diagrams and examples.

CAUTION

Do not press the Panel Computer touchscreen with any sharp objects. This practice may damage the unit beyond repair.

Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. UTICOR Technology, L.P. disclaims any proprietary interest in the marks and names of others.

Manual P/N MAN-UTPPC-001

**© Copyright 2003, UTICOR Technology, L.P.
All Rights Reserved**

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior written consent of UTICOR Technology, L.P. UTICOR Technology, L.P. retains the exclusive rights to all information included in this document.

MANUFACTURED and MARKETING by



UTICOR Technology, L.P.
4140 Utica Ridge Road
Bettendorf, IA 52722-1327

Phone: 1-563-359-7501 • Fax: 1-563-359-9094 • www.uticor.net



CONTENTS

CHAPTER 1 INTRODUCTION	
Manual Organization	1
Introduction	2
What you need to get started	3
Technical Support	3
CHAPTER 2 MODELS AND EQUIPMENT	
Models	5
Accessories	6
CHAPTER 3 SPECIFICATIONS	
Specifications	7
CHAPTER 4 INSTALLATION	
Installing the Industrial Panel Computer — Overview	9
Mounting	10
10.4" Industrial Panel Computer — Model AC220 and AC240 Outline Dimensions	10
10.4" and 12.1" Industrial Panel Computer Models AC220 and AC240 Cutout Dimensions	11
15" Industrial Panel Computer — Model AC250 Outline Dimensions	12
15" Industrial Panel Computer — Model AC250 Cutout Dimensions	13
CHAPTER 5 EXTERNAL COMPONENTS	
Connectors	14
CHAPTER 6 COMMUNICATIONS SETUP	
BIOS Setup	19
COM2 Serial Port Setup	19
CHAPTER 7 MAINTENANCE AND UPGRADES	
Upgrades	20
Expansion Card Installation	20
Maintenance	23
Replacing Front Door Assembly	23
Replacing Hard Disk Drive	25
Preserving Data	27
Touchscreen/Display	27
Touchscreen/Chemical Compatibility	28
Touchscreen Cleaning	28

CONTENTS



This page intentionally left blank.

Manual Organization

The table, below provides an overall description of the topics covered within this manual.

Chapters		
1	Introduction	Provides Manual Organization, and lists what you need to get started. Discusses how to get help with questions or problems you might encounter through Technical Support.
2	Models and Equipment	Provides you with a table listing the various models, their part numbers and features. Lists the optional equipment available.
3	Specifications	Specifications provide detailed information. Included are display size, connector and expansion card information, CPU type; service power requirements; operating and storage temperatures; available memory; serial communications specs; dimensions, weight, etc.
4	Installation	Shows the mounting and cutout dimensions for the panel models.
5	External Components	Provides location and description of the available connectors and expansion card slots. Provides location and description of switches, push buttons, display brightness potentiometer, and LEDs. Discusses Communication Setup.
6	BIOS Setup	Consult PCA1675 Embedded Processor Board User Manual, Part Number MAN-P1675-002.
7	Maintenance and Upgrades	Step-by-step instructions to install an expansion card, remove front assembly and replace hard disk drive are provided. Provides basic maintenance tasks to preserve data. Describes cleaning of touch screen and housing. Lists chemicals that may or may not be compatible with the touchscreen.

1 INTRODUCTION



Introduction

UTICOR Technology L.P.'s Panel Computer features a 700 Mhz Intel Celeron processor single board computer, in various sizes to fit your application needs. An active matrix LCD, resistive-type touchscreen is mounted in a rugged steel enclosure, with Zinc plating for optimum noise immunity, along with a flat NEMA4/4X sealing bezel to form an aesthetically pleasing package.

The Panel Computer is a full featured computer able to withstand harsh environments. Its rugged design, high performance and easy access for upgrade or maintenance make the Panel Computer ideal for applications requiring the highest reliability, as with all UTICOR electronic components.

The front assembly (includes display) of the Panel Computer swings open (except for the AC220, 10.4-inch model), and is simple to remove entirely, providing easy replacement and access to internal components.

The computers are rated to operate from 0 to 50°C, at a non-condensing humidity of 10–95%.

The Panel Computer is currently available in 4 sizes — 10.4-inch, 12.1-inch, 15-inch and 17-inch — and is designed to be protected from oil, dust or water damage when properly installed.

This manual will take you through the steps necessary to get your Panel Computers installed and running in the shortest possible time. This manual covers Models AC220, AC240, AC250, and AC270.





1 INTRODUCTION

What you need to get started:

Hardware

- Industrial Panel Computer Series:
 - AC220 — 10.4 TFT Display
 - AC240 — 12.1-inch TFT Display
 - AC250 — 15-inch TFT Display
 - AC270 — 17-inch TFT Display

Software

- Windows XP Pro

Technical Support



Technical Support

If you are having difficulty with a particular aspect of installation or setup, UTICOR technical support is available at **1-800-832-3647** or **FAX us at 1-563-359-9094**.

1 INTRODUCTION



This page intentionally left blank.



2 MODELS AND EQUIPMENT

Models

AC220 10.4" Display Industrial Panel Computer

AC240 12.1" Display Industrial Panel Computer

AC250 15.0" Display Industrial Panel Computer

AC270 17.0" Display Industrial Panel Computerf



2 MODELS AND EQUIPMENT



Accessories

There are replacement parts and optional equipment available to customize or upgrade the Industrial Panel Computer to fit your application. The following tables provide you with a list of this equipment.

Accessories	
Product	Part Number
32MB Disk on Chip Flash Memory	AC600
64MB Disk on Chip Flash Memory	AC601
128MB Disk on Chip Flash Memory	AC602
256MB Disk on Chip Flash Memory	AC603
40GB HDD	AC610
256MB MEM	AC615
512MB MEM	AC616
Standard Keyboard	AC620
Keyboard with Trackball	AC621
Multimedia I/R board	AC622
19" R/M Industrial Membrane Keyboard	AC623
2 Button Mouse	AC624
Modem, PCI, 56K V.90	AC630
2-way Video Splitter/Repeater	AC635
Shielded Video Cable - 6'	AC640
Shielded Video Cable - 10'	AC641
Shielded Video Cable - 30'	AC644
Shielded Video Cable - 60'	AC646
RS-232 Serial Cable - 6'	AC651
RS-232 Serial Cable - 10'	AC652
RS-232 Serial Cable - 30'	AC655
RS-232 Serial Cable - 60'	AC656



3 SPECIFICATIONS

COMPUTER SPECIFICATIONS

CPU Type:	700 Mhz Intel Celeron Processor
Memory:	128 MB minimum (expandable up to 512 MB)
BIOS:	Flash ROM
SSD:	Optional — Disk On Chip 32 MB minimum (up to 256 MB)
Drive:	40 Gb Hard Drive
Serial Ports:	1 dedicated RS-232 port, 1 RS-232/RS-422/RS-485 port
Parallel Port:	SPP/EPP/ECP supported (configurable to LPT1)
CD ROM:	Optional — external CD ROM drive (through USB port)
LAN:	32-bit PnP Ethernet controller 10 Base-T/100 Base-TX (RJ-45)
USB:	2 Ports (1.1 compliant)
PS/2 Interfaces:	1 Mouse, 1 Keyboard
Floppy DD:	Optional external Floppy Disk Drive (through USB port)
Operating System:	Windows XP Pro (Standard)
Watchdog Timer:	12 level timer with time-out intervals from 0.5 – 30,000 seconds

DISPLAY SPECIFICATIONS

Display:	AC220: 10.4" TFT Flat Panel AC240: 12.1" TFT Flat Panel AC250: 15.0" TFT Flat Panel AC270: 17.0" TFT Flat Panel
Touch Screen:	Analog Resistive Type
View Angle:	U/D: 150, R/L: 120
Screen Pixels:	AC220/AC240: SVGA 800 x 600 AC250: XGA 1024 x 768 AC270:
Display Brightness:	AC220: 230 nits AC240/AC250: 250 nits AC270:

3 SPECIFICATIONS



Backlight Bulb Life: **AC220:** 20,000 hours (manufacturer's rated minimum life)
 AC240: 40,000 hours (manufacturer's expected half-life rate)
 AC250: 35,000 hours (manufacturer's expected half-life rate)
 AC270:

VGA Output: XGA Output (60 ft. maximum)

MECHANICAL SPECIFICATIONS

Housing Material: Stud Mounted Metal Bezel — Black

Connectors: COM1 and COM2 D-SUB 9-pin male Serial Ports, LPT1 D-SUB 25-pin female Parallel Port, Two P/S 2 Ports, One RJ-45 for Ethernet, One D-SUB 15-pin female Video port, Two USB ports (1.1 compliant)

Dimensions: **AC220/AC240:** 11.250" x 14.250" x 6.988" (285.750 x 361.950 x 177.495 mm)
 AC250: 13.124" x 16.836" x 7.300" (333.350 x 427.622 x 185.420 mm)
 AC270: 18.766" x 14.749" x 7.543" (476.644 x 374.625 x 191.592 mm)

Weight: **AC220/240:** 15.4 lbs. (7.0 kg)
 AC250: 17.6 lbs. (8.0 kg)
 AC270:

Expansion Slots: 3 PCI slots for I/O cards
 PCMCIA: Optional (type 2) (uses one PCI slot)

Power Supply: 115/230 VAC @ 50/60 Hz, ATX 145 Watts

Cooling Fan: Optional


Environmental: NEMA 4/4X (indoor use only)
 Temperature: Operating — 0 to 50° C; Non-operating —20 to +60° C
 Relative Humidity: 10 to 95% noncondensing
 Agency Approvals: UL/CUL, CE Mark, FCC Compliant (pending)



4 INSTALLATION

INSTALLING THE INDUSTRIAL PANEL COMPUTER — OVERVIEW

Installing the **PANEL COMPUTER** requires the following three major steps:




4 INSTALLATION




Mounting

The Panel Computer is a panel-mount unit. The following diagrams show the outline and cutout dimensions necessary to mount the panel using the studs. All dimensions are in inches (mm in brackets []).

10.4" Industrial Panel Computer Model AC220 — Outline Dimensions




10.4" Industrial Panel Computer Model AC220 — Cutout Dimensions



4 INSTALLATION




12.1" Industrial Panel Computer Model AC240 — Outline Dimensions





4 INSTALLATION


12.1" Industrial Panel Computer Model AC240 — Cutout Dimensions



4 INSTALLATION




15" Industrial Panel Computer — Model AC250 Outline Dimensions





4 INSTALLATION


15" Industrial Panel Computer — Model AC250 Cutout Dimensions



4 INSTALLATION




17" Industrial Panel Computer — Model AC270 Outline Dimensions





4 INSTALLATION

17" Industrial Panel Computer — Model AC270 Cutout Dimensions




5 EXTERNAL COMPONENTS



CONNECTORS

Side Panel



Located on one side of the Industrial Panel Computers are the following connectors:

Two USB (Universal Serial Bus) Connectors

There are two USB connectors located on the side of the unit. Many devices now use this type of connector (i.e., scanner, printer, mouse, etc.). You can also use the USB to connect to an external Floppy Disk Drive or external CD ROM Drive. One or both ports may be used.



5 EXTERNAL COMPONENTS

One KEYBOARD Connector

A personal system/2 (PS/2)–style keyboard port.

One MOUSE Connector

A personal system/2 (PS/2)–compatible mouse port.

10/100 ETHERNET

10/100–megabit-per-second (Mbps) network interface controller (NIC) provides all the functions of a separate network card with Wakeup on LAN technology. The NIC supports both the 10 BASE-T and 100 BASE-TX Ethernet standards.

LPT1

Parallel Port (LPT1) is a 25-pin male D-Sub connector that is used to connect to a printer.




VIDEO

A 15-pin D-sub female connector for attaching a VGA monitor to the Panel Computer. The video signal sent to an external VGA monitor will duplicate the video resolution and image on the flat panel display.

COM1

COM2

COM1 and COM2 serial ports are 9-pin male D-Sub connectors. COM1 is a dedicated RS-232 port. COM2 is a RS-232/RS-422/RS-485 port. **Please Note: Manufacturer's default for COM2 is RS-232. To select RS-422 or RS-485, use the JP3 Jumper settings shown below. COM1 and COM2 Connector assignments are provided in the tables on the following page.**

COM 2 FUNCTION	JUMPER SETTING (pin closed)	JUMPER ILLUSTRATION
RS-232	Open	
RS-422	1-2, 5-6, 7-8, 9-10, 11-12, 13-14, 15-16, 17-18, 19-20	
RS-485	1-3, 4-6, 7-8, 9-10, 11-12, 13-14, 15-16, 17-18, 19-20	

5 EXTERNAL COMPONENTS



COM1 Connector

The COM1 Connector assignments (DSUB pinouts) are as follows:

<u>PIN</u>	<u>ASSIGNMENT</u>
1	DCD
2	RX
3	TX
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	RI/+5V/+12V selectable

COM2 Connector

The COM2 Connector assignments (DSUB pinouts) are as follows:

<u>PIN</u>	<u>ASSIGNMENT</u>		
	<u>RS-232</u>	<u>RS-422</u>	<u>RS-485</u>
1	DCD	TX–	TX–
2	RX	TX+	TX+
3	TX	RX+	RX+
4	DTR	RX–	RX–
5	GND	GND	GND
6	DSR	RTS–	NC
7	RTS	RTS+	NC
8	CTS	CTS+	NC
9	RI/+5V/+12	CTS–	NC

PCMCIA Slot (optional, uses one PCI slot)

PCMCIA (Personal Computer Memory Card International Association) are small form factor devices that are used in a variety of applications and devices, particularly in digital cameras, lap top computers, PDAs, and many other mobile devices. You can order a Panel Computer with one installed or install your own.

3 PCI Slots


The Panel Computer will support the addition of three 32-bit PCI (Peripheral Component Interconnect) Cards if you want to upgrade your system.



5 EXTERNAL COMPONENTS

On the other side of the Panel Computer you will find the **Power Connector** and a **Power Voltage Switch**. Use the power voltage switch to select 115 or 230 V AC. Also shown is the location of the optional fan.


Side Panel



5 EXTERNAL COMPONENTS



Rear Panel



Push Buttons

Located on the bottom rear panel, you will find a recessed **POWER ON** push button and a recessed **RESET** push button. There is also a recessed **DIMMER** potentiometer to adjust the display brightness on the 15" model (not available on the 10.4" and 12.1" model). Use a small flat blade screwdriver to adjust the DIMMER pot and to access the POWER ON and RESET push buttons.

LEDs

There are also 5 LEDs located on the bottom rear panel. They are labeled **PWR** to indicate power is applied to unit; **HDD** to indicate the hard disk drive is active; **10Mb**, **100Mb**, and **ACTIVE** all indicate Ethernet activity.



6 COMMUNICATIONS SETUP

BIOS Setup

Once you have the Panel Computer installed and the peripheral devices connected, you are ready to power up the computer. Press the POWER ON push button located on the rear panel of the computer (as described on page 18).

Consult the PCA1675 Embedded Processor Board Manual, part number MAN-P1675-002 to set up your Industrial Panel Computer's BIOS.

COM1 and COM2 Serial Port Setup

For wiring pinouts for COM1 and COM2, see page 20. For COM2, The default setting is RS-232. For COM2 RS-422 or RS-485 communications, install jumpers as shown on page 19. For more information, see the PCA1675 Embedded Processor Board Manual, part number MAN-P1675-002.

7 MAINTENANCE AND UPGRADES



UPGRADES

Expansion Card Installation


The Panel Computers can accommodate up to 3 expansion cards. To install an expansion card:



CAUTION: Before opening the Panel Computer or handling any expansion cards, be sure to protect the equipment from electrostatic discharge (ESD) by properly grounding yourself.

1. Disconnect the power source from the Panel Computer.
2. To open the rear of the enclosure, remove 9 screws from back captive panel. Panel is still held in place by 3 retaining tabs, one on top and two on the bottom. Just slide the rear panel to the right until the top tab aligns with the hole in the housing. Swing top out and lift back panel away from housing.


Rear panel



Retaining Tabs (3)

Screws (9)


3. Remove and set aside the screw that secures the slot cover where the expansion card will be installed. Discard cover.




Slot cover screw
(1 per cover)

PCI Expansion
Card Connectors

4. Remove the “card retaining bracket” from center posts by removing screw from back post holding card retainer. Lift up retainer and slide out of the slot in the front post.




5. Insert the expansion card into the backplane connector and reinstall the screw to secure the card's end plate to the enclosure.



7 MAINTENANCE AND UPGRADES



6. Reinstall card retainer bracket. Slide bracket into the slot in the front post and secure with a screw in the back post.
7. Adjust card retainer foot until it is securely against the top of the card that you have just installed. Tighten the screw to ensure that the card will remain properly seated in the backplane connector.
8. Replace the rear panel and reconnect the power source.



Maintenance




WARNING: Disconnect the Panel Computer from power source before opening the unit and disconnecting or removing any component. Failure to do so may result in electrical shock and/or damage to the unit.



CAUTION: Before opening the Panel Computer or handling any expansion cards, be sure to protect the equipment from electrostatic discharge (ESD) by properly grounding yourself.

Replacing Front Door Assembly

The entire front of the unit (which includes the display) is easily removeable from the panel chassis. To remove the front door assembly, reference the figures below and perform the steps on the following page:



7 MAINTENANCE AND UPGRADES



1. Disconnect Power Source and loosen the two spring-loaded thumbscrews on the door assembly.
2. The door assembly can now swing open.
3. Disconnect the three cables attached to the front assembly. (You will disconnect them from the door assembly, leave them attached to the components within the panel chassis.)
4. Disconnect the green grounding wire from the quick disconnect on the inside of the panel chassis.
5. Lift up on the door assembly to separate the interlocking hinges on the assembly from the chassis.
6. Mount the new door assembly on the hinges.
7. Reconnect cables.
8. Connect the 3 cables to the front door assembly, and then close the door and tighten the thumbscrews. (Make sure that you do not pinch any of the cables when closing the front door assembly.)
9. Reconnect power to the unit.

Replacing Hard Disk Drive




WARNING: Disconnect the Panel Computer from power source before opening the unit and disconnecting or removing any component. Failure to do so may result in electrical shock and damage to the unit.



CAUTION: Before opening the Panel Computer or handling any expansion cards, be sure to protect the equipment from electrostatic discharge (ESD) by properly grounding yourself.

In the event you should have to replace the hard disk drive in the unit, perform the following steps:

1. Disconnect power source.
2. Loosen the two spring-loaded thumbscrews on the front of the unit and swing open the door.
3. Disconnect the 2 cables from the disk drive.
4. Remove and set aside four screws in plate that secures hard disk drive to the panel chassis.



7 MAINTENANCE AND UPGRADES



5. Remove and set aside four screws that secure hard disk drive to the plate.
6. Attach new hard disk drive to the plate using the four screws that were removed earlier.
7. Secure plate with new hard disk drive attached to the panel chassis with the four screws that were removed earlier.
8. Reconnect cables.
9. Make sure that the 3 cables to the front door assembly are connected, close the door, and tighten the thumbscrews. (Make sure that you do not pinch any cables when closing the front door assembly.)
10. Reconnect power to the unit.

Preserving Data

Viruses can corrupt files; files can be inadvertently deleted; and hard-disk drives can fail after extended use. To avoid data loss, regularly back up the data files on the hard-disk drive. If you lose the contents of your hard-disk drive, you can reinstall programs, but your data files will be lost if you don't have a backup. We recommend you back up the hard-disk drive at least once a week, with a daily backup of those files that have been changed.

External Components

To clean the exterior computer cabinet, perform the following steps:

1. Place a grounding strap around your wrist to reduce the effects of electrostatic discharge (ESD).
2. Turn off the computer and any attached devices.
3. Use a small vacuum cleaner to remove any dust from the slots and holes on the computer.
4. Moisten a soft cleaning cloth with water and liquid dishwashing detergent.



Caution: DO NOT SOAK the cloth in the solution—you must not let the solution drip inside the computer.

5. Use the damp cloth to wipe the computer housing.

Touchscreen/Display

To ensure the longevity and effectiveness of the touchscreen please take note of the following precautions:

- Do not press sharp objects against the screen.
- Do not strike the panel with hard objects.
- Do not press the screen with excessive force.
- Once the panel is mounted and has power applied, do not place any objects over the ventilation slots. This will result in heat buildup and may damage the unit.



Touchscreen/Chemical Compatibility

The touchscreen has a polyester surface. The following list is provided to make you aware of the general compatibility between chemicals that may be present in your work environment and the polyester surface of the touchscreen. Use the chart to determine those chemicals that are safe to use around your Panel Computer and those that may harm the touchscreen. The list rates these chemicals as **E—Excellent**, **G—Good**, **F—Fair**, and **N—Not Recommended**. Because the ratings are for ideal conditions at 57°C, consider all factors when evaluating your application.

<u>Chemical</u>	<u>Rating</u>	<u>Chemical</u>	<u>Rating</u>
Acetone	G	Aniline	G
Auto fuel	E	Auto lubricants	E
Auto Hydraulics	E	Bromine (wet)	N
Butyl Cellosolve	E	Butyl Ether	G
Chloroform	G	Clorox	E
Coffee	E	Cupric Sulfate	E
Cyclohexanone	N	Cyclohexanol	E
Downy	E	Diethyl Ether	G
Dioctyl Phthalate	G	Ethyl Acetate	E
Ethanol	E	Ethylene Chloride	G
Fantastic	E	Formula 409	E
Grape Juice	E	Heptane	E
Hexane	E	Hydrogen Peroxide	N
Isopropyl Alcohol	E	Ketchup	E
Lemon Juice	E	MEK	F
Methylene Chloride	N	Mineral Acids (dilute)	E
Mineral Acids (strong)	G	Mr. Clean	E
Mustard	G	Naphtha	G
Phenol	N	Sodium Hydroxide (dilute)	G
Sodium Hydroxide (strong)	F	Sodium Hypochlorite	E
Spray 'N Wash	E	Tea	E
Toluene	E	Tomato Juice	E
Top Job	E	Trichloroacetic acid	F
Triethanolamine	G	Vinegar	E
Wisk	F	Xylene	E
Zinc Chloride	E		

Touchscreen Cleaning

The touchscreen has a scratch resistant coating. This adds a slight chemical barrier to the screen, but the coating's primary purpose is to protect the screen from abrasion. The touchscreen should be cleaned as needed with a soft cloth dampened with warm, soapy water.